


Getting Started Guide

Kenwood TK-3230DX



1. Power Switch/ Volume Control

Turn clockwise to switch ON the transceiver. To switch OFF the transceiver, turn counterclockwise until a click sounds. Rotate to adjust the volume level.

2. LED Indicator

Indicates the transceiver status.

3. PTT (Push to Talk) Switch

Press and hold, then speak into the microphone to transmit.

4. MENU Key

Press to perform various functions. Press and hold while switching the power ON to enter Setting Mode.

5. CAL Key

Press before making a call to alert the other party members, or press to select a unit ID to make a call.

6. MON Key

Press to monitor the current channel for activity

7. ▲ / ▼ Keys

Press to change the operating channel, to select a menu in Setting Mode, and to perform other functions.

8. SP/MIC Jacks

Insert the speaker/ microphone or headset plug into this jack